



1-2-3 Installation Instructions



Step One – Install 3 or 4 self-adhesive Gripper Tabs around the top of the bollard with “fingers” pointing down, and 3 or 4 more near the base of the bollard. If there is a small space to fill between the bollard and the cover, use 3 Gripper tabs evenly spaced around the bollard. To fill a larger space, use four Gripper Tabs at the top and bottom.



Step Two – Install Bollardgard over Gripper Tabs. Gripper Tabs should provide a tight installation which cannot be easily removed.



Step Three – Admire job well done.