

NATURAL GROUND ANCHORING INSTRUCTIONS

Tools Required:

- ◆ Rubber Mallet or Hammer and a wooden block
- ◆ 3/4" Ratchet Wrench
- ◆ 3/4" Wrench

Parts Included:

- ◆ Natural Ground Spike
- ◆ Spring
- ◆ Spring Hardware—(2) bolts, (2) locknuts, and (4) washers
- ◆ Post

CAUTION: Check Underground Utilities BEFORE Installing Natural Ground Anchor!!

1



- ◆ Identify desired anchoring location.
- ◆ Using a rubber mallet, tap the spike into the ground until the ring is flat against the ground. If you use a hammer instead, place a wood block between the hammer and spike to prevent damage to stem.

2



- ◆ Using the wrench and ratchet, attach the spring to the stem of the ground spike with the included spring kit.

3



- ◆ Insert the post into the other end of the spring and attach them using the remaining hardware in the spring kit.

4



- ◆ Please allow 24 hours for ground to settle for maximum stability.

****WARNING: MUST ANCHOR UNIT ON THE SAME LEVEL AS THE PARKING LOT FOR PROPER FUNCTIONALITY****

*** NOTE: For a more permanent application, use a post hole digger to dig out a hole 24" deep. Fill the hole with quick set cement. Place spike into the cement and allow appropriate dry time.**